



DETAIL C

| ITEM# | PART NO. & DESCRIPTION | ITEM# | PART NO. & DESCRIPTION |
|-------|------------------------------------|-------|----------------------------------|
| 1 | 315, CIRCUIT BREAKER PLUG HOLDER | 11 | PUSH ROD |
| 2 | 316, CIRCUIT BREAKER PLUG | 12 | 118. CIRCUIT BREAKER TRIP PIN |
| 3 | 317, CIRCUIT BREAKER DISC | 13 | M115A, TRIP BRACKET |
| 4 | 332, CIRCUIT BREAKER DISC BUSHING | 14 | 334, TRIP LEVER PIN |
| 5 | 331, CIRCUIT BREAKER DISC SHAFT | 15 | 312, CIRCUIT BREAKER BRACKET |
| 6 | 322, CIRCUIT BREAKER SLIDE PLUNGER | 16 | 314, CIRCUIT BREAKER FRAME |
| 7 | 3338, CLEVIS | 17 | 323, DISC SHAFT LOCK NUT |
| 8 | 329, SLIDE PLUNGER SPRING | 18 | 330, CIRCUIT BREAKER DISC SPRING |
| 9 | 313, CIRCUIT BREAKER TRIP LEVER | 19 | |
| 10 | M117, CIRCUIT BREAKER TRIP | 20 | |

ACME ELECTRIC WELDER CO.
 RESISTANCE WELDING EQUIPMENT
 TEL. 714-252-5330
 FAX 714-252-5335
 1338 N. KNOLLWOOD CIRCLE, ANAHEIM, CA

CIRCUIT BREAKER
 FOOT OP. SPARE PARTS LIST