



SEEDORFF
ACME Corporation


1338 N. Knollwood Circle
Anaheim, CA 92801
t: 714-252-5330
f: 714-252-5335
www.seedorffacme.com



Weld Force can be applied two ways, Direct or Indirect

Direct: Usually on a Press-Type Spot Welder or Seam Welder where the Weld Cylinder is directly above the Upper Electrode, Weld Wheel, or Tooling. Calculating the Area of the Piston or Diaphragm, multiplying the result by the Regulated Pressure at the Weld Cylinder, and adding the weight hanging from the Ram equates to the applied Welding Force.

The formula for calculating the Weld Force at the Electrodes is:





SEEDORFF
ACME Corporation

1338 N. Knollwood Circle
Anaheim, CA 92801
t: 714-252-5330
f: 714-252-5335
www.seedorffacme.com



Indirect: Usually on a Rocker Arm Spot Welder where the Weld Cylinder is not directly in-line with the Upper Electrode or Tooling.

The formula for calculating the Weld Force at the Electrodes is:

